

PRKR + TS

Movement-allowing wall tie for wooden frame. PRKR is screwed into the wooden frame with a tool installed in a power drill. The installation is fastened with a counter plate (VLR). The brick tie is installed into brick seams simultaneously with brickwork.

PRKR length: installation thickness + 70mm. Rustproof parts.

Consumption 4-5 pcs/m².

CE approved

